

# Heat Shield/Sun Reflectors



## NITE Heat Shield Sun Reflectors

NITE Heat Shield Sun Reflector Window Shades are custom cut for individual makes and models, making each one unique. Place these heat shields in your front windows to reflect the sun's glare and help keep your cab and sleeper cooler.

Bergstrom	Kysor	International	Kenworth/Peterbilt	Volvo	Freightliner
<b><u>Freightliner</u></b>					
<i>Cascadia Front Window</i>					
1000132411	4499013	ZNI740013	1000132411BSM	BSM1000132411	BSM 1000132411
<i>Century/Columbia Front Window</i>					
1000177374	4499020	ZNI740020	1000177374BSM	BSM1000177374	BSM 1000177374
<i>FLD 112/FL D120 Front Window</i>					
1000416685	4499077	ZNI740066	1000416685BSM	BSM1000416685	BSM 1000416685
<b><u>International</u></b>					
<i>9000I Series Front Window</i>					
1000177227	4499018	ZNI740018	1000177227BSM	BSM1000177227	BSM 1000177227
<i>ProStar Series Front Window</i>					
1000132409	4499014	ZNI740014	1000132409BSM	BSM1000132409	BSM 1000132409
<b><u>Kenworth</u></b>					
<i>T600/T800/W900 Front Window</i>					
1000176050	4499015	ZNI740015	1000176050BSM	BSM1000176050	BSM 1000176050
<i>T660 Front Window</i>					
1000323248	4499057	ZNI740056	1000323248BSM	BSM1000323248	BSM 1000323248
<i>T660 Side Window</i>					
1000323252	4499058	ZNI740057	1000323252BSM	BSM1000323252	BSM 1000323252
<i>T680 Front Window</i>					
1000522984	4499082	ZNI740069	1000522984BSM	BSM1000522984	BSM 1000522984
<i>T680 Side Window</i>					
1000523006	4499083	ZNI740070	1000523006BSM	BSM1000523006	BSM 1000523006
<i>T700/T2000 Front Window</i>					
1000320398	4499055	ZNI740054	1000320398BSM	BSM1000320398	BSM 1000320398
<i>T700/T2000 Side Window</i>					
1000320402	4499056	ZNI740055	1000320402BSM	BSM1000320402	BSM 1000320402
<b><u>Mack</u></b>					
<i>CH/CL/Vision Front Window</i>					
1000132413	4499011	ZNI740011	1000132413BSM	BSM1000132413	BSM 1000132413
<i>CH/CL/Vision Side Window</i>					
1000138867	4499012	ZNI740012	1000138867BSM	BSM1000138867	BSM 1000138867
<i>CX Front Window</i>					
1000360822	4499075	ZNI740064	1000360822BSM	BSM1000360822	BSM 1000360822
<i>CX Side Window</i>					
1000360826	4499076	ZNI740065	1000360826BSM	BSM1000360826	BSM 1000360826
<b><u>Peterbilt</u></b>					
<i>379</i>					
1000176058	4499016	ZNI740016	1000176058BSM	BSM1000176058	BSM 1000176058
<i>387</i>					
1000176060	4499017	ZNI740017	1000176060BSM	BSM1000176060	BSM 1000176060
<i>386/388</i>					
1000339434	4499064	ZNI740062	1000339434BSM	BSM1000339434	BSM 1000339434
<i>386/388 Side Window</i>					
1000339437	4499065	ZNI740063	1000339437BSM	BSM1000339437	BSM 1000339437
<i>579 Front Window</i>					
1000522984	4499082	ZNI740069	1000522984BSM	BSM1000522984	BSM 1000522984
<i>579 Side Window</i>					
1000525725	4499084	ZNI740071	1000525725BSM	BSM1000525725	BSM 1000525725
<b><u>Volvo</u></b>					
<i>VN Front Window</i>					
1000177230	4499019	ZNI740019	1000177230BSM	BSM1000177230	BSM 1000177230
<i>VN Side Window</i>					
1000251422	4499039	ZNI740036	1000251422BSM	BSM 1000251422	BSM 1000251422